


QUICKPLAY[®]

TARGET NET LITE



WARNINGS

EN

1. Check the frame is fully assembled and secured before attaching the net
2. Check the frame is secured to the ground before use.
3. Do not climb or hang on the structure. Regularly check for wear and tear.
4. Stop using if any part of it breaks, failure to do this may result in injury.
5. Keep away from heat sources.
6. This product is not suitable for children under 3 years of age.
7. Not suitable for use in high winds.
8. If product needs to be cleaned, hand wash only.

THANK YOU!

For choosing the QuickPlay Target Net Lite.

We hope you enjoy and
get years of use out of this product.

If you have any issues, please
do not return it to the store.
Instead contact us directly:

info@quickplaysport.com

We promise to resolve it
or your money back.

At Quick Play Sport we think sport is all about taking part. We develop innovative products that help athletes and coaches at all levels of sport, perform to the best of their ability. If you have any queries or suggestions about how we can improve our products, we'd love to hear them. Please feel free to get in touch.

**info@quickplaysport.com
+44 (0) 114 247 2327**

QUICKPLAY **TARGET NET LITE**

SET -UP GUIDE

